


# XTRONS

## Land Rover Steering Wheel Control Button Manual

For Land Rover Range Rover Vogue L405 (2013-2017)

For Land Rover Range Rover Sport L494 (2014-2017)

For Land Rover Discovery 5 LR5 (2017-2019)



1. Up Selection Button: Increases volume during media playback
2. Right Selection Button: Skips to next track during media playback
3. Slider Button: Slide up or down to adjust volume
4. Menu Button
5. Down Selection Button: Decreases volume during media playback
6. Left Selection Button: Returns to previous track during media playback
7. Phone Control Button: Manages Bluetooth calls—answer, dial, or end calls
8. Dashboard Menu Control Button
9. Voice Control Button

Volume can be adjusted by sliding the circle.

1. Automatic Cruise Control Set Button: Sets or increases speed
2. Return Button
3. Decrease Automatic Cruise Speed Button
4. Lane Keeping Assist Button
5. Set Cancel Button
6. Speed Limit Assist Button
7. Steering Wheel Heating Button

